






1




2




3




4



5




6




DIN EN 1717



1





Schlösser Armaturen GmbH & Co. KG

Im Dohm 3

57462 Olpe


GERMANY

www.schloesser-armaturen.de

info@schloesser-armaturen.de



DE Gebrauchsanleitung / Montageanleitung
GB Instructions for use / Assembly instructions
BR Brugsanvisning / Monteringsvejledning
DK Mode d'emploi / Instructions de montage
FR Gebruiksaanwijzing / Handleiding
NL Bruksanvisning / Montasjehandleiding
NO Instruksja obstuji / Instruksija montažu
PL Instruções para a uso / Manual de instalação
CZ Návod k použití / Montážní návod
HU Használati útmutató / Szerelési útmutató
SV Bruksanvisning / Monteringsanvisning
ES Modo de empleo / Instrucciones de montaje
RU Руководство пользователя /
Инструкция по монтажу
IT Istruzioni per l'uso / Istruzioni per l'uso
SK Montážny návod / Návod na použitie



10 0074644000201

09 0074644500201

08 0074504000001

07 0074554000001

06 0074404000001


05 0018590500001

04 0018011000001

03 0018590700002

02 0018162500001

01 0018192500001



0075552504001





max. 16 bar



max. 90°
65°

