













DIN EN 1717












DIN 1988
 DIN 3502
 DIN EN 1213
 bar
 °C

max. 16
 max. 90°
 5
 1
 0.5

0016401800001



- | | |
|----|----------------|
| 01 | 00181920000001 |
| 02 | 00185907000002 |
| 03 | 00183608000001 |
| 04 | 00185118000001 |
| 05 | 00181920000004 |
| 06 | 00181920000235 |



DE	Gebrauchsanleitung / Montageanleitung
GB	Instructions for use / Assembly instructions
DK	Brugsanvisning / Monteringsvejledning
FR	Mode d'emploi / Instructions de montage
NL	Gebruiksaanwijzing / Handleiding
NO	Bruksanvisning / Montasjeveiledning
PL	Instrukcja obsługi / Instrukcja montażu
PT	Instruções para uso / Manual de instalação
CZ	Návod k použití / Montážní návod
HU	Használási útmutató / Szerelési útmutató
SV	Bruksanvisning / Monteringsanvisning
ES	Modo de empleo / Instrucciones de montaje
RU	Пособие по монтажу Инструкция по монтажу
IT	Istruzioni per l'installazione / Istruzioni per l'uso
SK	Montážny návod / Návod na použitie



 Schösser Armaturen GmbH & Co. KG
 Im Dohm 3
57462 Olpe
GERMANY
 www.schoesser-armaturen.de
 info@schoesser-armaturen.de