






1




2




3




4



5




6




DIN EN 1717



1





DE Gebrauchsanleitung / Montageanleitung
GB Instructions for use / Assembly instructions
BG Brúgsanvísing / Monteringsvejledning
DK Mode d'emploi / Instruccions de montage
FR Gebruiksaanwijzing / Handleiding
NL Bruksanvisning / Montasjeveleiding
NO Instruksja obstuji / Instrukcja montażu
PT Instruções para uso / Manual de instalação
CZ Návod k použití / Montážní návod
HU Használati útmutató / Szerelési útmutató
SV Bruksanvisning / Monteringsanvisning
ES Modo de empleo / Instrucciones de montaje
RU Руководство пользователя /
Инструкция по монтажу
IT Istruzioni per l'uso / Istruzioni per l'uso
SK Montážny návod / Návod na použití



SCHLÖSSER
Armaturen



Schlösser Armaturen GmbH & Co. KG


Im Dohm 3

57462 Olpe

GERMANY

www.schloesser-armaturen.de

info@schloesser-armaturen.de



11 0074642500201

10 0074643200201

09 0074820000001

08 0074800200001

07 0074502500001

06 0074552500001


05 0074402500001

04 0018310800001

03 0018590700002

02 0018182500001

01 0018212500001



0077622502001



DIN 1988

bar

°C

max. 16
0,5

5
1

max. 90°
65°

